


Step 2: Mount the Headrail

Place the back lip of the headrail on the bottom lip of all brackets.



Push the front of the headrail firmly upwards, then roll the headrail up and towards the window opening until it snaps into the brackets.

Step 3: Install Cord Tensioner

IMPORTANT

In compliance with national safety regulations **shades will not operate unless the cord tensioner is installed correctly!**

After the shade is installed, the cord tensioner must be secured to the wall.

1. Position the tensioner as close to the shade as possible without interfering with the shade.

2. The tension on the cord/chain should be loose enough to allow free movement, but tight enough not to allow a hazardous loop.



Care and Cleaning

Young children can STRANGLE in cord and bead chain loops. They can also wrap cords around their necks and STRANGLE.



- Always keep cords and bead chains out of children's reach.
- Move cribs, playpens, and other furniture away from cords and bead chains. Children can climb furniture to get to cords.
- Do not tie cords together. Make sure cords do not twist together and create a loop.
- Attach tension device to wall or floor. This can prevent children from pulling cords and bead chains around their necks. Fasteners provided with the tension device may not be appropriate for all mounting surfaces. Use appropriate anchors for the mounting surface conditions.

Limited Lifetime Guarantee

Horizons Window Fashions warrants that its Horizons products - properly installed in a residential dwelling will be free from defects in materials and workmanship for as long as the original purchaser owns the product.

All fabric colors tend to lose their original intensity over time, and pull cords eventually wear out. This is considered normal wear and tear and is not covered by this guarantee. Abuse and misuse are not covered. Color lots vary and may not exactly match a previously ordered product. Repair is the purchaser's sole remedy under this guarantee.

This guarantee does not cover incidental or consequential damages, freight, installation or service calls (trip charges).

Horizons® Window Fashions

www.Horizonshades.com
06/2016

Installation Instructions for



Shades of Elegance™ Cassette Roller Shades




Congratulations on the purchase of your new Horizons Shades of Elegance Cassette Roller Shade!



SMALL CASSETTE INSTALLATION


Step 1: Install the Brackets

Outside Mount: Install above the wood trim or window frame. Use the rear bracket holes.



Care should be taken to ensure all brackets are level.

Inside Mount: Install inside the window frame. Use the top bracket holes.




Install the two outside brackets first, no further than 2" in from each end of the headrail.

Install the remaining brackets evenly spaced in increments of 24" or less. Care should be taken to ensure all brackets are level.

Step 2: Mount the Headrail

Place the back lip of the headrail on the bottom lip of all brackets.




Push the front of the headrail firmly upwards, then roll the headrail up and towards the window opening until it snaps into the brackets.

Continue to Step 3 on reverse.

LARGE CASSETTE INSTALLATION


Step 1: Install the Brackets

Outside Mount: Install above the woodwork or window frame. Use the rear bracket holes.



Care should be taken to ensure all brackets are level.

Inside Mount: Install inside the window frame. Use the top bracket holes.



Install the two outside brackets first, no further than 2" in from each end of the headrail.

Install the remaining brackets evenly spaced in increments of 24" or less. Care should be taken to ensure all brackets are level.